


After you have marked the mounting hole locations onto both sides of the fairing transfer those marks to this template. Because it is very hard to center the fairing the marks may be different on each side. Draw a line between the two upper marks then make a third mark halfway between them. Transfer this mark to both sides of the fairing drilling 1/4" holes here should center the fairing. Do the same for the lower marks. It is recommended to trim the rear ends of the fairing to 3/4" or less behind the holes to assure clearance to the frame and fuel tank (Cruisers may have a larger clearance allowing longer fairing sides). You can use this template to mark the cut but please save the trimmed piece and tape it to this template It would be very helpful to us at Laminar to have this template of the trim and hole locations along with the make, model and engine size of your motorcycle.



Motorcycle

Brand SUZUKI

Model SV1000/650

Size 1656/1000

Mail to:

Laminar LLC
2612 Croddy Way, Unit M
Santa Ana, CA 92704

Or

Please email photos to
laminar@laminarlip.com